



ECOCLEAN

MULTI PURPOSE CLEANER

Degreasing, cleans hygienic and deodorizes. EcoClean for a shining clean surface and freshness! Active Ecodor formula to remove the dirt directly without effortlessly scrubbing; CLEAN. For all water-resistant surfaces such as appliances, counter, table, bath, tiles, etc.

INSTRUCTIONS FOR USE

Spray directly onto the surface and let EcoClean do it's job for about one minute. Rub down with a cloth or a damp sponge. Rinsing is not necessary. With hard to clean surfaces/stains, let EcoClean set for a longer period then wipe well with clean cloth. Repeat treatment if necessary.

COMPOSITION

Surface active substances derived from grains, plant extracts, natural proteins, potassium carbonate, fragrance, CPC.

READY-TO-USE / CONCENTRATE STORE AT ROOM TEMPERATURE DOES NOT CONTAIN PROPELLANT PACKAGING CAN BE RECYCLED BIODEGRADABLE

ICON EXPLANATION



Turn the nozzle a quarter turn to the left to open. Squeeze the trigger handle backwards. Turn the nozzle a quarter turn to the right to close.



This packaging contains refill (concentrate) which allows you to create the right amount.

First read the instructions on the label carefully!



ATTENTION! This package contains 5X concentrate. Before use 1 part product with 4 parts water



All our products feature this icon. Our products are 100% environmentally friendly and biodegradable.



500 ML SPRAY BOTTLE......18.20.001

1000 ML REFILL 5X CONCENTRATE......18.20.002

LANGUAGE: NL | FR | EN | IT



ORO BY TRADING AS ECODOR

Address: Stoomloggerweg 8c, 3133 KT Vlaardingen, The Netherlands Postadres: Postbus 161, 3130 AD Vlaardingen, The Netherlands

T +31 10 248 11 22 // F +31 10 248 11 20 E info@ecodor.eu // W www.ecodor.eu

